



PROCEDURES

- ① INSTALL TREMIE TO OUTSIDE ANNULAR  
GROUT OUTSIDE ANNULAR FIRST
- ② RESET 2" TREMIE TO INSIDE ANNULAR  
COMPLETE GROUTING OF ANNULAR
- ③ POUR CONCRETE SLAB

① ANNULAR SECTION  
5687 CAMINO CIEL RD. SB